



Fridge slide handle Installation

Contents

- 1x Stainless steel handle bracket
- 4x Stainless 4mm button head bolts, washers and lock nuts

Tools Required

- Knife
- Drill
- 4.5mm drill bit
- 2.5mm Allen key
- 7mm spanner
- Long nose pliers (optional)

Procedure

1. Using a sharp knife remove blue plastic covering on both fridge slide levers.
2. Place the stainless steel bracket over the slide levers and mark the 4 holes.
3. Drill 4x 4.5mm holes in the outside of the slide levers only.
4. Bolt the bracket in place with stainless button head bolts, washers and lock nuts supplied.

TIP: use long nose pliers to hold the nuts inside the slide levers while threading the bolts from the outside.

