



Weber Baby Q Handle Bracket Installation

Contents

- 1x Stainless steel Handle relocation bracket
- 2x Stainless ¼" button head bolts (marked with a black line)
- 2x Stainless 6mm button head bolts, washers and nuts

Tools Required

- Phillips head screwdriver
- 4mm Allen key
- 10mm spanner

Procedure

1. Detach Weber handle by removing the two phillips head screws from inside the lid.
2. Discard the screws and metal spacers.
3. Bolt the handle onto the stainless steel relocation bracket using the two ¼" button head bolts marked with a black line supplied.
4. Bolt bracket onto the lid using the two 6mm button head bolts, washers and nuts supplied.

