



Pantry Slide Installation

Contents

- 1x Aluminum Base panel
- 1x Aluminum Front Panel
- 1x Aluminum Back Panel
- 2x Aluminum Side Panels
- 2x Aluminum Slide Packer Panels
- 2x 600mm Drawer Slides
- M5 Stainless Steel Bolts, Washers and Nuts
- M4 Stainless Steel Bolts, Washers and Nuts

Tools Required

- Drill and 4.5mm drill bit
- 2.5mm and 3mm allen key
- 7mm and 8mm spanner/socket

Procedure

1. Before Installing your new Pantry Slide kit ensure that the existing drawer runners are installed on the lowest mounting holes. (see picture 1) If they are not installed in the lower holes, remove existing pantry slide runners and install on the bottom holes.
2. Assemble the pantry using the M5 Bolts, Nuts and Washers Supplied. (tip. Install all bolts loosely before tightening any of the bolts)
3. Move the inner rail of the new drawer slides by pulling the slide all the way out with the lever depressed.

4. Bolt the inner rail to the new pantry with the pantry packer placed between the inner rail and the pantry using the M4 Bolts, Nuts and Washers (see picture 3) These holes are slotted to provide adjustment in step 8.
5. On the existing pantry, measure 30 mm down from the top of the pantry and mark a line. Place the drawer slide outer rail on the line and mark three holes. Repeat both sides. (the front of the new drawer slides should be flush with the front of the existing pantry)
6. Drill 6x 4.5mm holes in the existing pantry.
7. Bolt the outer rails to the existing pantry using the M4 Bolts, Washers and Nuts.
8. Carefully slide the new pantry onto the existing pantry (need to hold the levers down while sliding the pantry in the first time. Adjust the bolts on the side of the new pantry to allow clearance where necessary).



